

FANUC CONTROLLER R-30*i*B Plus

- Maintain high reliability by using R-30*i*B base hardware
- Improve performance by high speed CPU and process optimisation
- Memory Expansion DRAM: 128MB → 1 GB FROM: 128MB → Max 256 MB (64MB, 128MB, 256MB)
- Gigabit Ethernet support
- IIoT ready



R-30*i*B Plus *i*Pendant

• USB 3.0 support
• High speed, High resolution
VGA (640 x 480) → XGA(1024 x 768)



The Robot Controller R-30*i*B Plus

- User interface *i*HMI
- Using the programming guide, first-time robot users can create a program for a simple handling task and execute it in just 30 minutes
- Experienced FANUC users can program the robot as usual
- Improved efficiency by facilitated system setup and maintenance
- Shortened signal processing cycle
- New camera interface and simplified cable configuration for vision function

WWW.FANUC.EU

Graphical User Interface

iHMI



HOME screen

Unified design with CNC Reduced setup time with the minimum necessary menu structure

Image: Second State FBLE-078 Acto backup complete BECONNER LINE 0 100 Initial Secup Image: Second State Image: Second State Initial Secup Image: Second State Image: Second State Image: Secup Method Image: Second State Image: Second State Image: Secup Method Image: Second State Image: Second State Image: Secup Method Image: Second State Image: Second State Image: Secup Method Image: Second State Image: Second State Image: Secup Method Image: Second State Image: Second State Image: Secup Method Image: Second State Image: Second State Image: Secup Method Image: Second State Image: Second State Image: Secup Method Image: Second State Image: Second State Image: Secup Method Image: Second State Image: Second State Image: Secup Method Image: Second State Image: Second State Image: Secup Method Image: Second State Image: Second State Image: Secup Method Image: Second State Image: Second State Image: Secup Method Image: Second State Image: Second State Image: Secure Method Image: Second State Image: Second State Image: Secure Method Image: Second State Image: Second State

m (2)

TOTE TESTOOI LINE 0 TI ABORTED WORLD

luction Monito

d the DEADMAN so of Record the Po

Setup Guide

100

d the SHOFT key, and to record the position

R

IT S

Step by step procedure on the *i*Pendant to guide the user through the setup process

Program Creation Guide

Step by step procedure on the *i*Pendant to guide the user through program creation

Production Monitor

Graphic display of production status on the *i*Pendant

Technical information subject to change without prior notice. All rights reserved. © 2024 FANUC Europe Corporation

DAN