

EDUCATION CELL

Quick Start Guide

FANUC

STEP 1

Unpack the cell, wheel it into position and lock the wheels in place. The adjustable feet can be used for additional stability.



STEP 2

Download and read the Technical Documentation:
www.fanuc.eu/educational-package



LX-1-R0-MA-17-0-0001 Rev. B



STEP 5

Turn on the Main Power Switch and follow the instructions on the Teach Pendant to run the demo program.

STEP 4

Remove the Auto-T1-T2 switch key from inside the controller and insert into the switch on the front of the controller in the Auto position.

STEP 3

Remove the Teach Pendant from the accessory box and connect the Teach Pendant and Mains Power Cables.